



Installation Instructions for Rope Holders

You will need:

- Drill machine/hammer drill
- Drill bit, 10 mm diameter
- Measuring stick and pencil for marking on the wall
- Hammer (to drive plugs into the wall)
- Allen key, size 3
- Torx Bit TX25

Mark the desired height on the wall. Recommendation: approximately 85–90 cm above the floor or the edge of the step. The distance between the wall brackets should be around 80–100 cm.

Drill 6 cm to 6.5 cm deep into the wall and use a vacuum or blow to clear the drill hole. Insert the plugs into the holes.

Use the Torx bit to screw the anchor bolt into the wall, leaving about 2.2 cm to 2.5 cm of the thread visible. Now, screw on the rope holders and align them as desired.

Installation Instructions for Stainless Steel Rope Holders

You will need:

- Hammer drill
- Drill bit, 10 mm diameter
- Measuring stick and pencil
- Hammer (to drive plugs into the wall)
- Allen key, size 3

Mark the desired height on the wall. Recommended height: approximately 85–90 cm above the floor or stair edge. The distance between the wall brackets should be around 80–100 cm. Drill 6 cm to 6.5 cm deep into the wall and use a vacuum or blow to clear the drill hole. Insert the plugs into the holes.

Screw the double-ended screw into the rope holder and the other end into the wall. To securely mount the holder, insert a screwdriver through the hole for the final turns and use it as a lever. Proceed carefully to avoid damaging the rope holder.

Installation Instructions for the Rope

Lay the rope flat and pull it from the bottom up through the rope holders. To secure it, gently tighten the set screw by hand between two strands of the rope. Please do not use a drill or cordless screwdriver, and apply only light pressure to avoid damaging the rope.

Installation Instructions for End Caps

Place the end cap on the end of the rope. Turn the set screw between the strands to secure the rope. Please do not use a drill or cordless screwdriver, and apply only light pressure to avoid damaging the rope.

Installation Instructions for Rope Holders

You will need:

- Drill/ Hammer drill
- 10 mm drill bit
- Measuring tape and pencil to mark on the wall
- Hammer (to insert the wall anchors)
- Size 3 Allen key
- Torx Bit TX25

Shortening the Rope

Is your rope too long? No problem! Simply wrap tape around the desired spot, and cut through the middle of the taped section with a sharp knife, using a smooth blade - and you're done!